

The background features a dark grey, low-poly geometric pattern. Overlaid on this are white line-art outlines of various electronic components, including a monitor, a control panel with buttons, and a device with a screen and a dial. The TANCA logo, a stylized white 'T' with a curved bottom, is positioned to the left of the brand name. The brand name 'TANCA' is in a large, bold, white sans-serif font. Below it, the words 'AUTOMAÇÃO COMERCIAL' are written in a smaller, white, all-caps sans-serif font.

TANCA

AUTOMAÇÃO COMERCIAL

Manual de Instruções
Produto: **TL-120**



Manual de Instruções

Leitor de código de barras TL-120 Tanca



A Tanca tem imensa satisfação em tê-lo como cliente.

Para garantir um alto índice de satisfação de você nosso cliente, a equipe de colaboradores Tanca dedica todo o seu tempo na melhoria de seus produtos e serviços e na busca de novas parcerias.

Caso tenha algum tipo de dúvida ou problema com o equipamento, entre em contato com nosso suporte Técnico.

Telefone: (18) 3223.1593
(18) 3223.2069
(18) 3222.9616
(18) 3222.2377

Email: suporte@tanca.com.br

Plataforma de atendimento: <http://tancasuporte.mysuite2.com.br/empresas/tanc/central.php>

Importante

As informações contidas neste manual do usuário têm como objetivo orientar você a fazer a utilização correta de seu equipamento em poucos passos.

Índice

Setup Procedure	6
Default Setting	6
Interface Selection	6
Keyboard Interface	7
Funtion code selection	7
Keyboard language	7
Data Format	7
Code ID	7
Terminator	8
Caps lock	8
Overall prefix and suffix	8
Barcode Setting	9
Industrial 2 of 5	9
Standard 2 of 5	9
Interleaved 2 of 5	9
Matrix 2 of 5	9
Codabar	10
Code MSI	10
UK/Plessey	10
Code 93	10
Code 39	11
UPC-A	11
UPC-E	12
EAN 13	12
EAN 8	12
Code 128	13

GS1	13
Black and White Inverse Code	13
Scan Mode	13
Redundancy	13
Automatic induction	14
Beep	14
Reading length for each barcode type	15
Appendix	16
Default barcode parameter settings table	16
Default setting table	17
ASCII table	18
Sets the code parameter barcode	19
Sample barcodes	20
Anotações	21

Setup Procedure

The general procedure to program:

scan configuration codes directly

Example 1. To set the TL-120 parameters to 9 6 0 0, 8, 0, 1

1. scan “9600” (Baud Rate)
2. scan “8 bit” (Data Bits)
3. scan “None” (Parity)
4. scan “1 bit” (Stop Bit)

Remark:

1. “Reserved” is reserved for customized function.
2. This manual is subjected to change without notice.

Default Setting



Default

“*” Denotes default setting

Interface Selection

TL-120 interface can be detected automatically, no need configuration



*USB-HID

Keyboard Interface

Function code selection



Reserved 1



Reserved 2



Number Lock On



Number Lock Off



Reserved 3



Reserved 4

Keyboard language



US*



Japanese



Portuguese



Czech



Danish



Swedish



French



Italian



Norwegian



Spanish



Turkish-Q



English



Germany



Greek



Hungarian

Data Format

Code ID




*On



Off



*AIM code Off



AIM code On

Terminator




*Terminator allowed



None



Tab



Enter



0X0D+0D0A



Febravan ON



Febravan OFF

Caps lock



*Original Data



Upper Case compulsive



Lower case compulsive



Upper and lower case convert compulsive

Overall Prefix and Suffix



*Prefix Off



Prefix On



Prefix Setting



*Suffix Off



Suffix On



Suffix Setting

Example 1: Set "ST" as prefix. Refer to ASCII appendix, S= 0x53, T= 0x54, enable prefix, then set the custom prefix parameter to 5354, and save. **Step:** Scan below configuration codes in turn: "Prefix ON", "Prefix setting", "5", "3", "5", "4", "Save".

Example 2: Set "ED" + "ENTER" as suffix.

Refer to ASCII appendix, E= 0x45, D= 0x44, Enter=0x0D, enable suffix, then set the custom suffix parameter to "45440D", and save. **Step:** Scan below configuration codes in turn: "Suffix ON", "Suffix setting", "4", "5", "4", "4", "0", "D", "Save".

Barcode Setting


Industrial 2 of 5




On



*Off



*Not Verify check



Verify check
transfer



Verify check not
transfer

Standart 2 of 5



On



*Off



*Not Verify check



Verify check
transfer



Verify check not
transfer

Interleaved 2 of 5



On



*Off



*Not Verify check




Verify check
transfer



Verify check not
transfer

Matrix 2 of 5




On



*Off



*Not Verify check



Verify check
transfer



Verify check not
transfer

Codabar



On



*Off



*Not Verify check



Verify check
transfer



Verify check not
transfer



*Transmit start &
stop character



Not transmit start
& stop character



*Start and stop
character
ABCD / ABCD



Start and stop
character
ABCD / TN*E

Code MSI



On



*Off



*Not Verify check



Verify check
transfer



Verify check mod
10/10



Verify check mod
10/11



Verify check
Transfer



*Verify check not
Transfer

UK/Plessey



On



*Off



*Not Verify check



Verify check
transfer




Verify check mod
10/10

Code 93



On



*Off



*Not Verify check



Verify check
transfer

Code 39



On




*Off



*Not Verify check



*full Ascii 39



Standard 39



Verify check
transfer



*Verify check not
transfer



Transmit start and
stop*



Not transmit start
and stop*



Code 32 enable



Code 32 disable



Transmit code 32
prefix A



*Not transmit
code 32 prefix A



Reserved 1



Reserved 2

UPC-A



*On



Off



*Transmit leading
digit



Not transmit
leading digit




Convert to
EAN-13




*Not Convert to
EAN-13



*Verify check
transfer



*Verify check
not transfer



* Addenda 2 digit
disable



* Addenda 2 digit
enable



* Addenda 5 digit
disable



* Addenda 5 digit
enable

UPC-E



*On



Off



*Transmit leading digit "0"



Not transmit leading digit "0"



Convert to UPC-A



*Not Convert to UPC-A



*Verify check transfer



*Verify check not transfer



* Addenda 2 digit disable



Addenda 2 digit enable



* Addenda 5 digit disable



Addenda 5 digit enable


EAN 13



*On



Off



ISBN enable



ISBN disable



ISSN enable




*ISSN disable



*Verify check transfer



Verify check not transfer



* Addenda 2 digit disable



Addenda 2 digit enable



* Addenda 5 digit disable



Addenda 5 digit enable

EAN 8



*On



Off



Convert to EAN-13



Not convert to EAN-13



*Verify check transfer



*Verify check not transfer



* Addenda 2 digit disable



Addenda 2 digit enable



* Addenda 5 digit disable



Addenda 5 digit enable

Code 128



***On**



Off



ucc 128 enable




***ucc 128 disable**



***Verify check transfer**



***Verify check not transfer**



ISBN disable



ISBN enable

GS1



***On**



Off

Black and White Inverse Code



***On**



Off

Scan mode



***Manual Mode**



Continuous Scanning (always) On



Continuous Scanning (Flashing)



Reserved 1



Reserved 2



Reserved 3

Redundancy



***None**



1 time



2 times



3 times

Automatic induction

Need scanner support this function



Reserved 1



Reserved 2

Beep



*Off



On



Short beep
duration



*medium beep
duration



*Long beep
duration



Low Frequency



*Medium
frequency



High Frequency

Reading length for each barcode type



Indsutial 2 of 5
maximum length



Indsutial 2 of 5
minimum length



standard 2 of 5
maximum length



standard 2 of 5
minimum length



Matrix 2 of 5
maximum length



Matrix 2 of 5
minimum length



Interleaved 2 of 5
maximum length



Interleaved 2 of 5
minimum length



code 11
maximum length



code 11
minimum length



codabar
maximum length



codabar
minimum length



MSI
maximum length



MSI
minimum length



Code UK
maximum length



Code UK
minimum length



code 39
maximum length



code 39
minimum length



code 93
maximum length



code 93
minimum length



code 128
maximum length



code 128
minimum length

Appendix

Default barcode parameter settings table

Types	Read	Verify check	Transmit checking digit	Minimum length	Maximum length	ID
Industrial 2 of 5	N	N	N	6	255	U
Standard 2 of 5	N	N	N	6	255	S
Matrix 2 of 5	N	N	N	6	255	T
Interleave 2 of 5	YES	N	N	6	255	N
Code 11	N	YES	N	4	255	M
Codabar	YES	N	N	4	255	W
Code MSI	N	YES	N	4	255	Y
Code UK	YES	YES	N	1	255	X
Code39	YES	N	N	4	255	K
Code93	YES	YES	N	4	255	L
EAN-13	YES	YES	N	13	13	D
UPC-A	YES	YES	YES	12	12	A
EAN-8	YES	YES	YES	8	8	C
UPC-E	YES	YES	YES	7	7	B
Code128	YES	YES	N	1	255	G
RSS Truncated	YES	N	N	14	14	Z
RSS Limited	YES	N	N	14	14	Z
RSS Expanded	YES	N	N	1	255	Z

Gray background denotes default

Default settings table

List	Project Name	Description	Default
1	Scan mode		Manual scan
2	Interface setting		*Automatic
3	KB/USB	Keyboard language	US
4		Enable digital keypad	Disable
5		Caplock Ignore	Ignore
6	Data editing	COM trigger	Enter(0x0d)
7		Caps lock	Original data
8		CODE ID	OFF
9		Overall Prefix and Suffix	None
10	Beeper settings	Successful decoding sound tips	Middle tone Long duration
11	Other functions	Repeated	None
12		Inverse barcode decoding	OFF
13		Automatic induction	OFF

ASCII table

ASCII	HEX	DEC
NUL	00	0
SOH	01	1
STX	02	2
ETX	03	3
EOT	04	4
ENQ	05	5
ACK	06	6
BEL	07	7
BS	08	8
HT	09	9
LF	0a	10
VT	0b	11
FF	0c	12
CR	0d	13
SO	0e	14
SI	0f	15
DLE	10	16
DC1	11	17
DC2	12	18
DC3	13	19
DC4	14	20
NAK	15	21
SYN	16	22
ETB	17	23
CAN	18	24
EM	19	25
SUB	1a	26
ESC	1b	27
FS	1c	28
GS	1d	29
RS	1e	30
US	1f	31

ASCII	HEX	DEC
SP	20	32
!	21	33
"	22	34
#	23	35
\$	24	36
%	25	37
&	26	38
'	27	39
(28	40
)	29	41
*	2a	42
+	2b	43
,	2c	44
-	2d	45
.	2e	46
/	2f	47
0	30	48
1	31	49
2	32	50
3	33	51
4	34	52
5	35	53
6	36	54
7	37	55
8	38	56
9	39	57
:	3a	58
;	3b	59
<	3c	60
=	3d	61
>	3e	62
?	3f	63

ASCII	HEX	DEC
@	40	64
A	41	65
B	42	66
C	43	67
D	44	68
E	45	69
F	46	70
G	47	71
H	48	72
I	49	73
J	4a	74
K	4b	75
L	4c	76
M	4d	77
N	4e	78
O	4f	79
P	50	80
Q	51	81
R	52	82
S	53	83
T	54	84
U	55	85
V	56	86
W	57	87
X	58	88
Y	59	89
Z	5a	90
[5b	91
\	5c	92
]	5d	93
^	5e	94
_	5f	95

ASCII	HEX	DEC
'	60	96
a	61	97
b	62	98
c	63	99
d	64	100
e	65	101
f	66	102
g	67	103
h	68	104
i	69	105
j	6a	106
k	6b	107
l	6c	108
m	6d	109
n	6e	110
o	6f	111
p	70	112
q	71	113
r	72	114
s	73	115
t	74	116
u	75	117
v	76	118
w	77	119
x	78	120
y	79	121
z	7a	122
{	7b	123
	7c	124
}	7d	125
~	7e	126
DEL	7f	127

Sets the code parameter barcode



0



1



2




3




4



5



6



7



8



9



A



B



C



D



E



F



Save

Sample barcodes

Code 39



Codabar



Interleaved 2 of 5



Code 128



UPC-A with 5



EAN-13 with 2





Rua Marechal Floriano Peixoto, 166 - Vila Marcondes
Presidente Prudente - SP - CEP: 19030-020
(18) 3223-1593 / 3223-2069 / 3222.9616 / 3222.2377
www.tanca.com.br